

www.gninstruments.com Shanghai Cixi Instrument Co., Ltd

Manifold Gas Flow Controller/meter Operating Instructions



Shanghai Cixi Instrument Co., Ltd

1. product description

1.1 Uses and features

Mass Flow Controller(MFC)Used to accurately measure and control the mass flow of gas. They play an important role in scientific research and production in various fields such as semiconductors and integrated circuit industries, special materials disciplines, chemical industry, and industrial, pharmaceutical, environmental protection, and vacuum lamps. Typical applications include: electronic process equipment such as diffusion, epitaxy, CVD, oxidation, plasma etching, sputtering, and ion implantation; and coating equipment, optical fiber smelting, microreaction devices, mixed gas distribution systems, capillary measurement, Gas chromatographs and other analytical instruments

1.2 Main Specifications

1	Flow range:	(0~5, 10,20,30,50,100,200,300,500) SCCM		
		(0~1,2,3,5,10,50,100,200,500) SLM		
2	Accuracy	±1.5%F.S		
3	Linearity	±0.5~1.5%F.S		
4	Repeatability	±0.2%F.S		
5	Responding time	Electrical characteristics:10sec gas characteristics:		
		(1~4) sec		
6	Differential pressure range	0.1~0.5MPa		
7	Max pressure	3МРа		
8	Working temperature	0~70℃		
9	Digital value	RS485 MODBUS		
10	Analog value	DC 0~5V		
11	Power supply	DC +15V, flow meter<400mA, flow controller<600mA		
12	Electrical connection	DB15		
13	Leakage rate	1×10 ⁻⁸ SCCSHe		
14	Material of base	316L Stainless steel		
15	Seal material	FKM, nitrile butadiene rubber, chloroprene rubber		
16	Glad hand	Ф3, Ф6, Ф10, 1/8″,1/4″, 3/8″		

note:

The mass flow meter and mass flow controller are usually calibrated with nitrogen (N2).

The unit of mass flow is stipulated as: SCCM (Standard ml/min); SLM(Standard l/min)

Standard state stipulates: temperature ----273.15K (0°C);


Pressure -----101325 Pa(760mm Hg)

F.S (Full Scale); Full-scale value

Shanghai Cixi Instrument Co., Ltd

1.3 Working principle

The excellent accuracy, robustness and reliability of the CX series gas mass flow controllers stem from our unique sensor probes. The sealed probe consists of two sensing elements - speed sensor and temperature sensor, which can automatically correct the influence caused by the change of temperature and pressure. The meter circuit heats the speed sensor to a constant value higher than the gas temperature, and then measures the cooling effect of the gas flow. The flow is calculated under the principle that measuring electric power consumed which used to maintain a constant temperature difference, which is proportional to the mass flow of the gas. Both sensors are standard platinum resistance temperature detectors (RTD). Platinum RTD wire is wrapped around a solid ceramic core, firm and reliable. The entire sensor is sealed in а 316 stainless steel packing case.




Picture(3)Working principle diagram

Shanghai Cixi Instrument Co., Ltd


2. Quick installation guidance

2.1 Shape and installation dimensions



图三、CX Dimensions of mass flow controller

2.2 Form of gladhand




Picture(4)Installation diagram of double ferrule splice


As shown in picture 4, when installing the splice, after installing the front ferrule, back ferrule, and nut, tighten the nut and the splice by hand, then tighten with a wrench (The imported Swagelok splice requires a 1.25-turn wrench to tighten.) to ensure air tightness. Note that double wrench should be used, with one wrench stuck in the joint and the other to turn the nut. Especially when removing the nozzle, double wrench must be used, otherwise it will cause loosening of the joint and affect the sealing.

Shanghai Cixi Instrument Co., Ltd

2.3 Cable connection plug



Picture(5) ±15VDC Power supply diagram



Picture(6) 24VDC Power supply diagram

3. Functional operation details

3.1 start-up operation

Check that there should be no leakage at the connection of each equipment, the temperature and pressure of the gas source should be stable, and the circuit should be connected correctly according to the product instructions.



Shanghai Cixi Instrument Co., Ltd

3.2 Connecting with Flow Display Instrument

After the start-up operation, the valve switch of the flow indicator is set to the "off" position, the setting value is set to zero, then the air is turned on. After the zero is stabilized, the valve control position is turned on, and then the setting value is adjusted to the required flow value, then the actual flow value will change with the setting value.

3.3 Shutdown Operation

First set the value to zero, then cut off the air circuit, and then power off.

4.Attention

4.1 Adding filter

The use of gas must be purified, avoid dust, liquids and oil. If necessary, install a filter. If a liquid source bottle is connected to the outlet of the flowmeter, install a one-way valve at the outlet of the flowmeter to prevent the liquid from flowing back and damaging the flowmeter.

4.2 Use for corrosive gases

The materials used for the flowmeter channel are: SUS 316L (00Cr17Ni14Mo2), SUS 417J1 (00Cr30Mo2), fluorine rubber and other corrosion resistant materials. It can be used to control general corrosiveness when other users use corrosive gas and organic solvent gas under the condition that the user's system has no soda, low leakage, diligence, and good use. It should be stated at the time of ordering. With special corrosive gases, all sealing materials must be changed accordingly

4.3 Installation position

The controller is best installed to maintain the level of the installation surface, but not particularly sensitive to the location, can be installed at any position, if the zero offset is found when installing in non-horizontal position, you can adjust the zero point after work.

Shanghai Cixi Instrument Co., Ltd

4.4 Valve sealing

The valve of the mass flow controller is a regulating valve, not a shut-off valve, and cannot be used as a shut-off valve. The user should be equipped with a shut-off valve. In particular, when users use corrosive gases, a shut-off valve should normally be added to the inlet and outlet ports of the mass flow controller to ensure work safety. After long-term work, if the leakage rate of the controller valve port is within 2%F.S, it is normal. If the leak is greater than 2% of full scale, service should be performed.

4.5 Calibration and conversion of different gases

The flow meter is usually calibrated by nitrogen (N2). If other gas calibration is required, special orders should be made with the salesperson when ordering.

When users of flow controllers calibrated with nitrogen use other gases, they can be converted by the conversion factor of the appendix.

5.General anomaly judgment and treatment

Phenomenon	Possible reasons	treatment methods	
	The air source is not open and the air is not accessible	Connect the gas source and open the gas path	
No sim flance often	Didn't set the target flow	Reference detailed operation 3.4	
No air flow after	Filter clogging	Change the filter	
power on	Control valve failure	Check the valve	
	Circuit failure	Repair circuit	
	Zero deviation	Reference detailed operation 3.4	
	Sensor failure	Change sensor	
Flow control	Circuit failure	Repair circuit	
unstable	Valve pollution	Clean the valve, change the seal	
unstable	The pressure of the gas	Improve gas source pressure and	
	source is too low or unstable.	stabilize gas source pressure	
When the valve is	Control valve failure	Check the valve	
closed, there is	High inlet pressure	Reduce inlet pressure	
still a larger flow.	Channel clogging	Clean MFC channel	
Display can't reach full scale	Set target flow below full scale	Check the set target flow	
Todoi Tuli Sodie	Other circuit faults	Repair circuit	
Zero instability at	Circuit faults	Repair circuit	
no flow	Sensor failure	Change sensor	

Shanghai Cixi Instrument Co., Ltd

6.Guarantee, warranty and service

6.1 Product assurance and warranty

- 6.1.1 The MFC/MFM products produced by our company are within two years of shipment. If the user is used according to the instructions, and the product has not suffered physical damage, pollution, modification or refurbishment, we guarantee the quality of the material, processing and performance of the product. If there is a problem, the product will be repaired free of charge.
- 6.1.2 After receiving the goods, the user has the responsibility to check and check the goods and to inform the Sales Department of the company in a timely manner by fax, telephone or e-mail.
- 6.1.3 During the warranty period, the product must be repaired by the company or authorized service center, otherwise, the warranty of the product is invalid.
- 6.1.4 The maintenance is free of charge within one year's warranty. If the warranty is over, users will be informed of the components and maintenance costs that need to be replaced before maintenance. After repair, the repair part is guaranteed within 90 days. The warranty includes vulnerable parts (such as Teflon or seal ring).
- 6.1.5 Users who have used toxic, contaminated or corrosive gas products will not be responsible for repair or warranty if they are not shown to clear the pollution and clean the treatment.

6.2 Requirements for the use of warranty

- 6.2.1 The gas must be clean and free of particulate matter and liquid. This requires the installation of <30 M filter in the upstream gas path of MFC/MFM.
- 6.2.2 The input gas pressure must conform to the product's withstand voltage standard and should not exceed the maximum pressure required by the product.
- 6.2.3 The gas used in the product must be compatible with the sealing material selected by the user. The user is responsible for using each gas according to the applicable safety regulations. Incorrect use of the product will make the warranty invalid. The damage caused by incorrect use can not be attributed to the company.
- 6.2.4 Requirements for electronic circuits: we must carefully connect the wiring of the system according to the regulations. Incorrect wiring will cause permanent damage to the internal circuit boards of the products. MFC power supply needs high voltage interference less than 5mV voltage regulator.
- 6.2.5 Connection of gas path: the sealing fittings must be carefully installed to ensure that all sealing pipes are inspected individually and without scratches.
- 6.2.6 It is forbidden to disassemble MFC/MFM on its own. If the damage is caused by self dismantling, the warranty promised by the company is invalid.



Shanghai Cixi Instrument Co., Ltd

Appendix: Gas flow conversion factor

Gas	code	specific heat(Calorie /g°C)	Density (g/L0℃)	Change rate
Air	008	0.2400	1.2930	1.006
Ar	004	0.1250	1.7837	1.415
AsH ₃	035	0.1168	3.4780	0.673
BBr ₃	079	0.0647	11.1800	0.378
BCI ₃	070	0.1217	5.2270	0.430
BF3	048	0.1779	3.0250	0.508
B ₂ H ₆	058	0.5020	1.2350	0.441
CCI ₄	101	0.1297	6.8600	0.307
CF ₄	063	0.1659	3.9636	0.420
CH ₄	028	0.5318	0.7150	0.719
C ₂ H ₂	042	0.4049	1.1620	0.581
C ₂ H ₄	038	0.3658	1.2510	0.598
C ₂ H ₆	054	0.4241	1.3420	0.481
C ₃ H ₄	068	0.3633	1.7870	0.421
C ₃ H ₆	069	0.3659	1.8770	0.398
C ₃ H ₈	089	0.3990	1.9670	0.348
C ₄ H ₆	093	0.3515	2.4130	0.322
C ₄ H ₈	104	0.3723	2.5030	0.294
C ₄ H ₁₀	111	0.4130	2.5930	0.255
C ₅ H ₁₂	240	0.3916	3.2190	0.217
CH ₃ OH	176	0.3277	1.4300	0.584
C ₂ H ₆ O	136	0.3398	2.0550	0.392
C ₂ H ₃ Cl ₃	112	0.1654	5.9500	0.278
CO	009	0.2488	1.2500	1.000
CO ₂	025	0.2017	1.9640	0.737
C_2N_2	059	0.2608	2.3220	0.452
Cl ₂	019	0.1145	3.1630	0.858
D_2	014	1.7325	0.1798	0.998
F ₂	018	0.1970	1.6950	0.931
GeCl ₄	113	0.1072	9.5650	0.267
GeH₄	043	0.1405	3.4180	0.569
H ₂	007	3.4224	0.0899	1.010
HBr	010	0.0861	3.6100	1.000
HCI	011	0.1911	1.6270	1.000
HF	012	0.3482	0.8930	1.000
HI	017	0.0545	5.7070	0.999
H ₂ S	022	0.2278	1.5200	0.844



Shanghai Cixi Instrument Co., Ltd

He	001	1.2418	0.1786	1.415
Kr	005	0.0593	3.7390	1.415
N ₂	013	0.2468	1.2500	1.000
Ne	002	0.2464	0.9000	1.415
NH ₃	029	0.5005	0.7600	0.719
NO	016	0.2378	1.3390	0.976
NO ₂	026	0.1923	2.0520	0.741
N ₂ O	027	0.2098	1.9640	0.709
O ₂	015	0.2196	1.4270	0.992
PCI ₃	193	0.1247	6.1270	0.358
PH ₃	031	0.2610	1.5170	0.691
PF ₅	143	0.1611	5.6200	0.302
POCI ₃	102	0.1324	6.8450	0.302
SiCl ₄	108	0.1270	7.5847	0.284
SiF ₄	088	0.1692	4.6430	0.348
SiH ₄	039	0.3189	1.4330	0.599
SiH ₂ Cl ₂	067	0.1472	4.5060	0.412
SiHCl ₃	147	0.1332	6.0430	0.340
SF ₆	110	0.1588	6.5160	0.264
SO ₂	032	0.1489	2.8580	0.687
TiCl ₄	114	0.1572	8.4650	0.206
WF ₆	121	0.0956	13.2900	0.215
Xe	006	0.0397	5.8580	1.415
Ve	000	0.0331	3.0300	1.415